



Venti Maxima Series VFD Operating Manual



VMX : Version 2.0 Eng/BM



- ① Press to Power ON / OFF to Start and Switch Off Fan
- ② Press to Decrease Fan Speed
- ③ Press to Increase Fan Speed
- ④ For Diagnostic / Setting only – Do not touch

START/STOP	Click Run/Stop/Reset in Level 0 menu, click Confirm in 1/2/3/Password input menu
“+”	Level 0 menu click to increase the setting gear, 1/2/3 click, long press to increase the parameter value
“-”	Level 0 menu click to decrease the setting gear, 1/2/3 click, long press to decrease the parameter value
⑤ “RUN” Light	Always on when running and off when stopped;
⑥ “STOP” Light	Always on when stopped and off when running;
⑦ “ALARM” Light	Always on when there is a fault, and off when it is not in a fault state;

For Installation use/ Dimensions





Venti Maxima Manual Operasi Kipas



- ① Tekan untuk mulakan atau pemberhentian kipas
- ② Tekan untuk mengurangkan kelajuan kipas
- ③ Tekan untuk menambah kelajuan kipas
- ④ Untuk kegunaan Diagnostik sahaja – **JANGAN Tekan**
- ⑤ Lampu menyala apabila kipas beroperasi / Tiada bila berhenti
- ⑥ Lampu menyala apabila kipas berhenti / Tiada bila beroperasi
- ⑦ Penggera : Menyala bila kipas ada masalah
 - Tutup Suis dan pasang semula
 - Jika lampu masih menyala : baca dan catat kod terpapar di skrin.
 - Panggil Venti Servis dan maklumkan Kod – untuk reset sendiri atau juruteknik Venti akan pergi ke lokasi anda

- For Sales & Service inquiries



VENTI SDN BHD (1390023-D)

Unit 2-1, Level 2, The Podium, Tower 3

UOA Business Park, No 1 Jalan Pengaturcara U1/51A Seksyen U1
40150 Shah Alam.

Tel: Sales - 0122315731 Service - 0123009881

www.venti-fans.com